



## DATA AND SPECIFICATIONS

### 5000 Series ModuMaxx Stacking Arm Chair



5000-20 Stacking Chair

*ModuForm stacking chairs are engineered for institutional durability and suitable for continuous use in demanding, active environments.*

- Chair Types:**                      **Styles:**
- Stacking chairs shall be capable of stacking up to 20 high
  - **Dimensions:** The chair seat and back shall be wider and the armrest higher than chairs of this type for maximum comfort: 24"W x 24"D x 33"H x 18"SH. Chairs less than this size shall not be acceptable.
  - **Weight:** 10.8 lbs

#### Materials & Construction:

High-impact grade copolymer polypropylene with UV light stabilizers prevents fading and anti-static additive reduces dust attraction. Pigmented color is homogeneous throughout the entire material rather than a surface skin of color.

#### Colors:

Available in five colors to meet aesthetic considerations; can be color coordinated with other ModuForm products.

**Colors:** • 700 Sandstream • 318 Burgundy • 426 Slate Blue • 845 Grey Flannel

#### Finish:

Matte/suede (non-gloss), easy to clean.

#### Construction:

One-piece injection molded construction without steel or wood components of any kind.

- 36 interlocking reinforcing rib cells on the underside of the seat and five points of reinforcement at rear legs for maximum strength.
- Bowed ribs to add to the strength of the chair back.
- Chair feet are at double angles to reduce stress and maintain stability when in a rock-back position.

#### Flammability:

Meets the State of California Technical Bulletin 133 flammability test requirements. Test results conducted by a recognized independent laboratory are available. **Passes:** Passes ASTM F1561-94, standard performance requirements for plastic chairs for outdoor use. Class A – Residential, Class B – Non-residential. Passes ANSI – BIFMA – ANSIx5.1-1993 for General Purpose office chairs. Test results conducted by a recognized independent laboratory are available.

#### Chemical Resistance:

Chlorine solution, acetone, blood, urine, feces, wine, whiskey, beer, vinegar, salt solution.

#### Cleaning:

Chairs can be easily cleaned with a damp cloth and mild detergent. Steam cleaning does not harm the product. Can be sanitized with bleach-based cleaners to aid in the control of infections and blood borne pathogens.

#### Accessories:

- Chair stacking dolly for stack mobility assembled.

## GENERAL INFORMATION

**Warranty:** ModuForm's standard warranty provides for repair or replacement due to defects in the material and work-manship for a period of five years. See warranty for details. **Shipping:** All units shipped assembled. **Ordering Information:** See current Price List for prices and how to order. **DISCOUNTS AVAILABLE.** For assistance call our Customer Service Department toll-free at 800-221-6638, visit our website at [www.moduform.com](http://www.moduform.com) or call your local ModuForm Representative.

